


FIG.2

22 22 21 25 21

23 24 20 22a 22b 42 22b 22a 21a 21b 21b 21a 22a 22

22b 42 35a 36 35b 34 32 31 36 33 42 41 36 30






FIG.5





FIG.6
34 33

WHITE CONTROL OF THE CO







FIG.8






FIG.10

FIG.11






FIG.12



SET.UP ADDRESS SUSTAIN
PERIOD S2, PERIOD A2, PERIOD U2 SUSTAIN PERIOD U1 ADDRESS PERIOD A1 SET-UP PERIOD S1

FIG.13



... 0V -50V-170V_180V 350V_{200V} = 250V_{200V} SET-UP ADDRESS SUSTAIN PERIOD S2, PERIOD U2 SUSTAIN PERIOD U1 ADDRESS PERIOD A1 SET-UP PERIOD S1 V1 V2 SCAN -------ELECTRODE -------SUSTAIN ELECTRODE PRIMING DATA -

FIG.14

:== 250V₂₀₀V 0V -50V >0 V07-----SET-UP ADDRESS SUSTAIN PERIOD S2, PERIOD U2 SUSTAIN PERIOD U1 ADDRESS PERIOD A1 SET-UP PERIOD S1 SCAN III DATA ELECTRODE

350V_{200V}

SUSTAIN ELECTRODE

PRIMING ELECTRODE

100V

FIG.15






FIG.16



0V -50V -170V $250V_{200V}$ 350V_{200V} E 150V_{50V} 0V 100V 0V 70V -----SET-UP ADDRESS SUSTAIN PERIOD S2, PERIOD A2, PERIOD U2 SUSTAIN PERIOD U1 ADDRESS PERIOD A1 SET-UP PERIOD S1 V1 V2 SCAN JLL...L. ELECTRODE SUSTAIN ELECTRODE PRIMING ... ELECTRODE

FIG.18

FIG.19



SET-UP ADDRESS SUSTAIN PERIOD S2, PERIOD UZ SUSTAIN PERIOD U1 ADDRESS PERIOD A1 SET-UP PERIOD S1

FIG.20

